


CFTSL4**

Thorsman faceplate to be used with plastic or metal trunking.


INSTALLATION

Press straight down on faceplate and snap into trunking.



REMOVAL

Insert flat side of screwdriver between faceplate and trunking. Rotate screwdriver 90° to remove the faceplate.



*Thorsman is a division of Schneider Electric.
** Denotes color.